

Front Full Aluminum Doors For Can-Am Maverick X3

ZP-YJ-030609-010

SAUTVS®

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This FRONT FULL ALUMINUM DOORS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Remove the three groups of screws and nuts shown in the figure and take down the lower half door.



3. Remove the three groups of screws and nuts shown in the figure and the rivets at the lower end, and take down the upper half door.



4. Fasten the M6 U-shaped clip, and fix the aluminum door at the position shown in the figure with three M6*40 hexagon socket screws, three M6 flat washers and three M6 locknuts.



Front Full Aluminum Doors For Can-Am Maverick X3

ZP-YJ-030609-010



5. Fix the upper end of the aluminum door at the position shown in the figure with two M6 * 16 socket head cap screws, two M6 flat washers and one M6 nut with washer.



6. Installation is complete.

(NOTE: Refer to the same installation method for the other side)

