

Light Fairing Kit For Ski-Doo

ZP-YJ-030603-154

SAUTV5

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This LIGHT FAIRING KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. First use the tool to fix the vehicle tail light bracket rivets to take off, then disconnect the tail light harness plug-in, and finally remove the tail light bracket.

3. Move the vehicle tail light to the new bracket.



4. Put the new taillight bracket back on the vehicle, connect the taillight harness plug-in, and finally refasten the taillight bracket with new extractor rivets.

NOTE: When installing the taillight bracket, the rear hook needs to be stuck into the limit notch on the vehicle

Light Fairing Kit For Ski-Doo

ZP-YJ-030603-154



5. Installation complete.

