

Radiator Deflector Kit For Can-Am Maverick X3

ZP-YJ-030603-146

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This RADIATOR DEFLECTOR KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Remove the hood of the vehicle and the front bumper trim panel.

3. After removing the mesh grille and radiator deflector, replace the new radiator deflector, then put back the mesh grille, and finally put back the front bumper trim panel.



Radiator Deflector Kit For Can-Am Maverick X3

ZP-YJ-030603-146

SAUTV5



4. Installation completed.

