

# Mono Seat Cow Kit for Can-Am Ryker

ZP-YJ-030603-137

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

### IMPORTANT

This MONO SEAT COW KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Snap the trim panel onto the rear shelf of the original vehicle.

(Note: the retaining valve on the back of the trim panel needs to be snapped into the fixing holes on the surface of the shelf).



4. Installation is complete.



3. Press hard on the end of the decorative plate until you hear the snap sound, then screw on the fixed valve from the bottom of the shelf.