

# Center Fairing With Light For Can-Am Spyder RT

SAUTVS®

ZP-YJ-030603-140

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

## IMPORTANT

This CENTER FAIRING WITH LIGHT KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Products and accessories.



3. Open the original vehicle cushion and front storage box, then remove the cushion under trim panel and front wing trim panel on the side of the gas pedal.



4. Remove the center fairing bracket from the original vehicle, then snap the fairing with lights onto the center bracket. Turn the fairing back to its original position after the installation is completed.



# Center Fairing With Light For Can-Am Spyder RT

ZP-YJ-030603-140



5. Disconnect the original daytime running light harness plug-in, use the adapter cable that comes with the product to dock with its plug-in, and dock the other end to the original vehicle socket. Pull the extension cable to the center fairing and connect it to the light harness. Finally, install back the previously removed accessories and decorative plates.

6. Installation completed.

