

# Front Combination Fender Flares For Can-Am

## Maverick X3

ZP-YJ-030610-013

SAUTV5®

### BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

### IMPORTANT

This FRONT COMBINATION FENDER FLARES KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

### INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product and accessories.



3. The split fender flares need to be assembled before installation.



4. There are 8 positioning points on the flying wing decorative panels on both sides of the front of the original vehicle. Use a 3mm drill to drill out screw holes, and then install the assembled fender flares on the original vehicle with screws.

# Front Combination Fender Flares For Can-Am Maverick X3

ZP-YJ-030610-013

SAUTV5<sup>®</sup>



5. There is a fixed point at the rear of the fender flare, but since the original vehicle has no positioning point here, it is necessary to drill holes with a drill (3mm) according to the screw holes on the fender flare, and then fix it with screws.

(The other side of the fender flare can be completed according to the above steps)



6. Installation completed.

