

### **BEFORE YOU BEGIN**

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

#### **IMPORTANT**

This AIR INTAKE ACCENTS WITH PRE-FILTER KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

#### INSTALLATION INSTRUCTIONS

- 1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
- 2. The decoration part has a filter on the left and no filter on the right.



3. Open the air inlet cover on one side first (there is a small pull ring on the air inlet cover, which can be opened by lightly pulling it), clip the decorative part without filter to the cover, and then buckle the air inlet cover.







4. On the other side, you need to unscrew the 2 screws under the air inlet, remove the cover, and snap the decorative piece with the filter, after installing it, buckle the cover back and screw on the screw (there is a steel clip at the inner end of the cover, and The card slots in the same position of the vehicle body correspond to each other, so when installing the cover, install the front end first, and then the rear end).

# Air Intake Accents With Pre-Filter For Can-Am Ryker

## ZP-YJ-030603-093











5. Installation completed.

