

Air inlet filter For Can-Am Maverick X3

ZP-YJ-030603-105

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This AIR INLET FILTER KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Products and accessories.



3. First take off the original vehicle after the air inlet cover, after placing the filter, in accordance with the screw holes on the filter, using an 8MM drill bit to punch three fixed holes after taking off the filter placed on the side of the spare, playing a good hole in the air inlet cover and then installed back on the original car (when installing the air inlet cover note that the edges have a bayonet, you need to correspond well with the slot on the vehicle body).



Air inlet filter For Can-Am Maverick X3

ZP-YJ-030603-105

4. Take out the sponge strip in the kit, tear off the anti-adhesive film, stick a full circle along the edge of the filter, then put the filter on the air inlet cover, and use the nylon snap to fix.



5. Installation completed.

