

Front Bumper Guard For Can-Am Ryker

ZP-YJ-030606-007

SAUTVS®

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This FRONT BUMPER GUARD KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Products and accessories.



3. Fix the frame of the front bumper and the chassis with screws, and then install the front bumper and the lower protector on the frame.



Front Bumper Guard For Can-Am Ryker

ZP-YJ-030606-007

SAUTV5



4. Remove the engine cover and radiator cowling of the vehicle.



5. Install the front bumper on the fairing, and then fix it with the original screws of the vehicle.



6. Clamp the steel clips in the accessory package on the two brackets shown in the figure, install the brackets on the bottom chassis of the front bar frame (one on each side), fix them with screws, and finally reinstall the engine cover.

Front Bumper Guard For Can-Am Ryker

ZP-YJ-030606-007

SAUTV5



7. Installation complete.



NOTE: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.