

# Plastic Hand Guards Kit For Can-Am Outlander

ZP-YJ-030603-082



## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

## IMPORTANT

This HAND GUARDS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Snap the handguards on the handlebars.



4. Installation completed.



3. Secure the handguards to the handlebars with the riding clamps.

