

HAND GUARD FOR CAN-AM OUTLANDER

ZP-YJ-030603-094



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This Hand Guard is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Install the decorative cover on the hand guard.



2. First clip the bracket on the back of the hand guard. One end of the hand guard surface is fixed to the support at the back with screws, and the back of the hand guard at the other end is fixed with screws with flat pads. Screw the support and the hand guard with nuts.



3. Install the parts in the order shown in the picture.



HAND GUARD FOR CAN-AM OUTLANDER

ZP-YJ-030603-094



4. Distinguish between left and right. Insert one side of the hand guard bracket into the end of the car handle and fix the other side with a pipe clamp. First fix the screw at position 1 (m6x20) (put a rubber pad on the pipe clamp before screwing the screw), and then place the screw at position 2 (m6x16). Do not tighten the screw at position 2, and tighten the screw after adjusting the angle of the hand guard. The screw at the end of the handle also needs to be tightened (please refer to the same steps for the installation of the hand guard on the other side).



5. Hand guard installation completed.

