Side Mirrors for Polaris Snowmobiles

ZP-YJ-030505-014

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

The Side Mirrors are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Using the Figure 1 for reference, locate mirror base to hood. (Note locator feature).



2. Use the drill and a $\frac{1}{4}$ drill bit to drill out the center of the mounting hole.

3. Install the mirrors and secure with screws and nuts supplied with the kit. Torque to 6-8 in. lbs. (0.68-0.90 Nm) Figure 2.

NOTE: Brake duct may be removed to make the forward mirror fastener easier to install.



4. Installation finished.

