

# FENDER FLARES KIT INSTALL INSTRUCTIONS



ZP-YJ-030503-011

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

## FRONT FENDER FLARES:

1. Drill holes under the front fender.



2. Align the red line on the fender flares with the outside of the fender. The big hole pointed by red arrow on the lower side is aligned with the plastic buckle that comes with the car.



3. Refer to the hole on the fender flare, and drill a hole on the front fender with a pistol, then fix it by install the plastic buckle.



4. Align the lower fender flare with the mounting hole on the upper fender flare, and fix them together with a plastic buckle.



5. Align the red line edge of the lower fender flare with the outer edge of the front fender, refer to the hole on the fender flare, and drill a hole on the front fender with a pistol, then fix the fender flare with plastic buckle.



# FENDER FLARES KIT INSTALL INSTRUCTIONS



ZP-YJ-030503-011

## REAR FENDER FLARES:

1. Refer to the location holes on rear fender flares, and drill holes on the rear fender.



2. Align the red location line on rear fender flare with the outside edge of rear fender, then refer to the location holes, drill installation holes on rear fender with pistol drill, and fix the fender flare to rear fender with plastic buckle.



3. Align the upper edge of lower rear fender flares with the front edge of upper rear fender

flares, then align the semi-circle on the lower rear flare with the circle shape location on the vehicle.



4. Refer to the location hole on the rear fender flares, and drill installation holes on the rear fender with pistol drill, then fix rear fender flares to rear fender with plastic buckles.

