

Rock Slider Kit For Polaris General XP 4 1000

ZP-YJ-030506-027

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This ROCK SLIDER KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.



INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Use 12 M8*50 socket head cap screws, 12 M8 lock nuts and 6 parts G to assemble parts A, C, D, E and parts B, C, D, E, do not tighten the screws.



3. Remove the 4 screws on the left and right under the frame and keep them as a spare.



Rock Slider Kit For Polaris General XP 4 1000

ZP-YJ-030506-027

4. Use the original vehicle screws to fix the side bumpers on the frame in turn, tighten the M8*50 screws.



5. Installation completed.

