

Iron Wheel Well Block Offs For Polaris RZR PRO XP

ZP-YJ-030510-013

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This IRON WHEEL WELL BLOCK OFFS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product and accessories.



3. First, the right (passenger seat) fender placed on the rear wheel in front of the body, with an 8mm drill bit, along the indicated location of the hole to the body for drilling, after the nylon expansion buckle pressed into the hole to play a fixed role.



4. Place the fender on the left (main driver's seat) on the front body of the rear wheel, the holes on the fender are aligned with the holes on the car (a total of 3), and then press the nylon expansion buckle into the hole to play a fixed role.

Iron Wheel Well Block Offs For Polaris RZR PRO XP

ZP-YJ-030510-013

SAUTV5



5. Installation completed.

