

# TAILLIGHTS for CAN AM COMMANDER 2021

ZP-YJ-030602-021



## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

## IMPORTANT

The Red or Smoked Black Taillights Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

## INSTRUCTIONS

### Installation

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Open the side panel of the tail box. Take out the two screws and remove the panel as the direction of the arrow. Repeat the steps for the other side.



2. Remove the nuts that fixed the original lamp and take out the plug. Remove the taillight.



3. Place the taillight at the taillight mounting place, screw the nuts and insert the connector.



# TAILLIGHTS for CAN AM COMMANDER 2021

ZP-YJ-030602-021



4. Install the side panels of the tail box.  
Installation of the taillights finished.

