

# TAILGATE HANDLE LEVER FOR CAN-AM COMMANDER

ZP-YJ-030603-065



## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

## IMPORTANT

Your HANDLE LEVER is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Remove all the screws of the tailgate, and detach the tailgate from the rear cargo box.



3. Remove the bolts, nuts and springs from the original handle lever, as spare parts.



4. Install the new handle lever.



5. Install the tailgate of the rear cargo box.



6. Installation finished.