Folding Side Mirrors For Can-Am Maverick X3





BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This FOLDING SIDE MIRRORS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

- 1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
- 2. Use the screw in the accessory to pass through the screw hole on the vehicle's A-pillar pole, then unscrew the adjusting screw at the bottom of the reversing mirror, adjust the reversing mirror to a proper angle, and then tighten the screw. Finally, install the reversing mirror on the vehicle's A-pillar pole and fix it with the screw. (The other side can be installed in the same way)







Folding Side Mirrors For Can-Am Maverick X3







3. Installation completed.

