

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

Your Front Mesh Grill Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTRUCTIONS

Installation

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Prepare the mesh grill and the hardware as shown.



2. Remove the bumper and mesh grille of the original vehicle, and remove the three steel clips on the back of the original mesh grille for standby.



3. Install the three steel clips of the original mesh grille on the new mesh grille, then install the new mesh grille back on the bumper and fix it with two screws.



Front Mesh Grill with LED Light for Can Am Maverick X3

ZP-YJ-030603-110



5. Installation complete.



4. Install the bumper back into the vehicle, and then connect one end of the harness plug-in of the new mesh grille to the original vehicle harness plug-in, and the other end to the position lamp harness plug-in.

