

FRONT GRILLE TRIMS FOR CAN-AM RYKER

ZP-YJ-030603-077



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This Front Grille Trims is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Use the mounting bracket to drill holes on both sides of the middle net. The diameter of the drill hole is 5.5mm.

Note: The marking position must be aligned.



2. Insert the nut from the fitting bag into the hexagonal hole on the mounting bracket.



3. Fix the mounting bracket on both sides of the net with screws.



4. Clamp the narrow section of the air inlet onto the mounting bracket, and attach the wide end to the upper part of the middle net on both

FRONT GRILLE TRIMS FOR CAN-AM RYKER

ZP-YJ-030603-077



sides, and drill with a 5.5mm drill bit.



5. Use screws to install air intakes on both sides of the net.



6. The installation is complete.

