ZP-YJ-030503-110

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This is Rear Cargo Tailgate exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

 Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
Product picture



3. Assemble part 1, part 2 and part 3 with 6 hexagon screws of M6*20, 6 lock nuts and 6 flat washers, as shown below:



4. Remove the four screws on the rear frame of vehicle and set them aside. Install the rear tailgate in the position shown in the figure, and fix the tailgate firmly with the removed screws of rear frame. The installation is complete.





Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

