CLASSIC HOOD ACCENT PANEL FOR CAN-AM RYKER

ZP-YJ-030603-073



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This Classic Hood Accent Panel is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Remove the machine cover and drill with a 6mm drill bit at the anchor point indicated by the arrow.

Note: The drill bit should be tilted at an angle to the mounting plate when drilling (as shown below). Vertical drilling is not allowed.





2. Fix the cover decoration plate on the drilled cover with M5*12 inner hexagon screws, flat pads and square nuts.



3. Install the cover with decorative plate on the vehicle, then the installation finished.

