

Accelerator Pedal for Can-Am Spyder

ZP-YJ-030603-098



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

The Accelerator Pedal are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Remove the accelerator pedal of the original vehicle, keep the screws for later use, as shown in the picture:



2. Install the new accelerator pedal and fix it with the removed screws, as shown in the picture:



3. Installation finished.