SAUTV

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This Rear Bumper is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.



2. Assemble Part 1, Part 2 and part 3 by connecting casing 4 and connecting casing 5 with eight M8*55 hex socket screws and eight M8 locknuts. The direction of casing is shown below:





For Ranger XP 1000:

1. After opening the tailgate at the Angle below, lift up and remove the tailgate, as shown in the picture:



2. Install part 6 on the lower bracket of the rear of vehicle with two M8*90 screws and two M8

Rear Bumper with LED Light for Polaris Ranger XP 900 1000 ZP-YJ-030506-033

locknuts, as shown in the picture:



3. Fix the mounting bracket 6 at the bottom of the frame with four M6*20 self-tapping external hexagon screws. Install the bar body on the iron support with four M8*65 hex socket screws and four M8 locknuts, and tighten all screws.







4. Installation finished.



For Ranger XP 900:

1. Install part 6 on the lower bracket of the rear of vehicle with two M8*90 screws and two M8 locknuts, as shown in the picture:



Rear Bumper with LED Light for Polaris Ranger XP 900 1000 ZP-YJ-030506-033



2. Fix the mounting bracket 6 at the bottom of the frame with four M6*20 flange self-tapping screws. Install the bar body on the iron support with four M8*65 hex socket screws and four M8 locknuts, and tighten all screws.







3. Installation finished.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

