

# Front Bumper Panel for Polaris Sportsman 400 450 500 600 700 800 X2

ZP-YJ-030503-128

SAUTV5

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

## IMPORTANT

This Front Bumper Panel is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Products and accessories:



3. First remove the front bumper cover plate of the vehicle, replace and install the new front bumper panel. As shown below:

(Note: When the panel is installed, push down after it is stuck.)



4. The installation is complete.



**Note:** Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.