

Front Bumper for POLARIS Sportsman 500 700 800

SAUTV5

ZP-YJ-030506-034

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This Front Bumper is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Products and accessories:



3. First remove the cover plate of the front fascia of the vehicle (from the bottom right corner of the cover plate from inside to outside), then unscrew the screws fixing the front fascia, and remove the front fascia (disconnect the wiring harness plug-in of the headlamp of the vehicle before removing the front fascia). As shown below:



Front Bumper for POLARIS Sportsman 500 700 800

ZP-YJ-030506-034



plate, seize the top first and then press it firmly.)



4. Remove the headlamp from the front fascia of the vehicle and install it on the new front fascia in the original way, as shown in the figure:



5. Reassemble the front fascia of the installed headlamp to the vehicle, connect the wiring harness plug-in of the headlamp, and finally install the front fascia cover plate. As shown below:

(Note: When installing the front fascia cover

Front Bumper for POLARIS Sportsman 500 700 800

ZP-YJ-030506-034

SAUTV5



6. The installation is complete.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.