

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

The side mirrors are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Product picture

#1 matching screw: M12*55 4 pieces

#1 matching nut: M12 4 pieces #1 matching nut: M12 4 pieces

#2 matching screws: M6*20 4 pieces

#2 matching nuts: M6 4 pieces #2 matching nuts: M6 4 pieces



2. First, unscrew the screws at the A-pillar of the original vehicle and replace them with the M12*55 screws that come with the product. Then, fix the installation bracket of the side mirror on the screws (pay attention to distinguishing the left and right sides of the installation bracket). As shown below:





3. Fix the side mirror on the mounting bracket using the M6*20 screws and matching flat washer nuts in the accessory package. (The side mirror on the other side can be installed in the same way.). As shown below:







4. Installation finished.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.