## **BEFORE YOU BEGIN**

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

## **IMPORTANT**

This Front Full Windshield is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle. 2. Use 2pcs M6\*20 screws, 2pcs M6 flat pads, 2pcs M6 nuts and 2pcs M6\*10 outer hex screws with pads to fix the windshield on the front frame with two iron brackets. As shown in the figure:





**Note:** Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

