

Front Full Windshield for CFMOTO ZForce 950

SAUTVS®

ZP-YJ-031211-002

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *Front Full Windshield* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

ASSEMBLY TIME

Approximately 5 minutes.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Assemble the seal strip to the windshield with screws and nuts, and then fix the full windshield to the frame with Six clamps.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.