

Plastic Front and Rear Door Net Buckle for Polaris Ranger 900 570 1000 XP 2013-2020



ZP-YJ-030503-132

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

These *Buckles* are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product picture



1. Remove the front door buckle support of the original vehicle, replace it with a new support, and then fix it with the original vehicle screws. (The other side is installed in the same way). As the picture shows:

Note: The product is marked left and right, pay attention to check to avoid installation mistakes!



Plastic Front and Rear Door Net Buckle for Polaris Ranger 900 570 1000 XP 2013-2020



ZP-YJ-030503-132



2. Remove the rear door buckle support in the same way as above, replace it with a new support, and then fix it with the original screws and nuts. (The other side is installed in the same way). As the picture shows:

Note: The surface of the product is marked with arrows, and install in the upward direction of the arrows (The rear bracket does not distinguish between left and right).



2. Installation finished.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.