

# Front Central Hood Fenders for Can-Am Maverick X3

ZP-YJ-030603-172

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

## IMPORTANT

This FRONT CENTRAL HOOD FENDERS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Marked accessories require final installation.



3. According to the picture, assemble the product first.



4. Remove the front fascia top cover and the cover trim panel from the original vehicle.





# Front Central Hood Fenders for Can-Am Maverick X3

ZP-YJ-030603-172

SAUTVS®



5. Remove the center mesh, headlights and daytime running lights connected to the original front fascia cover, then replace the original cover and reinstall the new front fascia cover (the original cover has 2 through-hole rubber plugs, which need to be pried down and installed on the original cover), and then install the previously removed headlights, center mesh and other accessories back to the original position after the replacement is completed.





# Front Central Hood Fenders for Can-Am Maverick X3

ZP-YJ-030603-172

6. Reinstall the assembled trim pieces back into the vehicle, then install the last accessory of the product under the brackets attached to the ends of the fascia cover plate and secure it using the Velcro fasteners.



7. Installation completed.

