

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This REAR COMBINATION ALUMINUM FULL DOORS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product image.



3. Use 5 M6*15 hexagonal screws and 5 M6 anti-loosening nuts to assemble parts 1 and 2, then use 2 M5*16 hexagonal screws and 2 M5 anti-loosening nuts to attach part 5 to the side of the aluminum door, and finally install the adhesive strip on the lower edge of the aluminum door.



Rear Aluminum Full Doors for Can-Am Maverick X3 MAX

ZP-YJ-030609-012



4. Dismantle four sets of screws and nuts shown in the figure, and remove the lower half door, as shown in the figure.



5. Dismantle three sets of screws and nuts shown in the figure, unscrew the top and bottom screws, and remove the top half of the door.



6. Fix two M6 U-shaped clips at the position shown in the figure of the aluminum door, then fix the aluminum door at the position shown in the figure with three M6*40 hexagon socket head cap screws, three M6 flat washers, and three M6 locknuts.

Rear Aluminum Full Doors for Can-Am Maverick X3 MAX

SAUTVS®

ZP-YJ-030609-012



7. Fix the upper end of the aluminum door at the position shown in the figure with two M6*16 hexagon socket head screws and two M6 flat washers and complete the installation. (The installation is same on the left and right sides.)

