

Cargo Bed Box Carrier Kit for Can-Am Maverick X3

SAUTV5

ZP-YJ-030603-170

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This CARGO BED CARRIER KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Image of products and accessories.



3. Snap the steel clips from the kit onto the fixing holes of attachment (2), and then use the screws to assemble attachments (1) and (2) together.



Cargo Bed Box Carrier Kit for Can-Am Maverick X3

SAUTV5

ZP-YJ-030603-170

4. After attachments ③ and ④ are also fitted with steel clips, they are then assembled to ① and ②.



5. After removing the original rear cargo box from the vehicle, disassemble the skeleton and heat shield at the back as well as the movable nuts on both sides, and assemble it to the new rear cargo box in its original position.



6. Install the new rear cargo box on the vehicle and secure it with the original screws of the vehicle.



Cargo Bed Box Carrier Kit for Can-Am Maverick X3

ZP-YJ-030603-170

SAUTV5

7. Installation completed.

