

# Front Fascia for Can-Am Maverick X3

ZP-YJ-030603-166

SAUTV5

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

## IMPORTANT

This FRONT FASCIA KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product picture.



3. Remove the double-sided adhesive film on the daytime running lamp frame on both sides of the product, assemble the frame on the front fascia (distinguish the left and right sides). As shown in the figure:



4. Remove the engine cover and front trim cover. As shown in the figure:



# Front Fascia for Can-Am Maverick X3

ZP-YJ-030603-166



5. Remove the front fascia of the vehicle from the decorative cover plate, and the grille, daytime running lights and headlights of the vehicle also need to be dismantled. The removed screws and steel clips shall be kept for using later. As shown in the figure:



6. Clamp the steel clips just removed onto the new front fascia in the original position, then install the original daytime running lamps. After completing the previous steps, reassemble the front fascia onto the decorative cover plate, and then reinstall the original headlights. As shown in the figure:



# Front Fascia for Can-Am Maverick X3

ZP-YJ-030603-166

SAUTV5



7. Refit the original grille and the brackets on both sides to the new front fascia. The reflectors on both sides of the original front bumper also need to be removed and fixed to the new front fascia. As shown in the figure:



# Front Fascia for Can-Am Maverick X3

ZP-YJ-030603-166

8. After all the assembling are completed, the whole trim cover plate can be installed back on the vehicle and install the engine cover at last. As shown in the figure:

**(Note: An I-shaped rubber on the original front fascia needs to be pried off and fixed to the new front fascia.)**



9. Installation completed.

