Center Rearview Mirror Kit for Polaris XPEDITION XP/ADV 2024





BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This *Center Interior Mirror Kit* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Center Mirror Installation

Product picture



1. First, take out the two steel clips from the product accessories package, and insert them into the reserved holes of the original vehicle, and then remove the mirror from the mounting base. As the picture shows:







2. Use the matching screws to fix the mounting base on the original roof, and finally install the rearview mirror back on the mounting base. As the picture shows:

Center Rearview Mirror Kit for Polaris XPEDITION XP/ADV 2024

ZP-YJ-030505-024









3. The installation is complete.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.