Front Storage Rack Latch Hinge Kit for Polaris Sportsman Scrambler 550 850 1000 ZP-YJ-030503-145

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *Front Storage Rack Latch Hinge Kit* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

PRODUCT AND ACCESSORIES



INSTALLATION INSTRUCTIONS

 Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
First, put two cylindrical limit posts into the fixing rod (The one without holes on the surface first, and then the one with holes). As shown in the figure:





SAUT

3. Remove the original latch kit from the vehicle. Thread the new anchor rod through the bottom of the storage box to the surface, then thread the matching retaining pins through the hole in the anchor rod, and finally hook the latches onto the retaining pins. As shown in the picture:

Front Storage Rack Latch Hinge Kit for Polaris Sportsman Scrambler 550 850 1000 ZP-YJ-030503-145







4. The installation is complete.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.