

Front Bumper Guard for Can-Am Outlander 450 500 570

ZP-YJ-030606-013

SAUTVS®

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *Front Bumper Guard* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Attach Parts 1 and 2 to Part 4 through two bushings (Part 3) using 4pcs M8*40 hex screws and 4pcs M8 lock nuts. As shown in the picture:



3. Remove the 2pcs screws and nuts from the vehicle frame for use. As picture shows:



4. Fix the lower part of the front bar to the frame with 2pcs M8*30 outer hex screws, and then fix the upper part of the front bar to the upper position with 2pcs screws and 2pcs nuts removed from the vehicle, tighten the screws. As shown in the picture:



5. The installation is complete.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.