

# Rear Bumper Guard for Can-Am Outlander 450 500 570

ZP-YJ-030606-014

SAUTV5

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *Rear Bumper Guard* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Assemble Parts 1, 2 and 3 with 2pcs M8\*45 hex screws and 2pcs M8 lock nuts. As shown in the picture:



3. Remove 4pcs screws and 4pcs nuts from the back of the vehicle and save them for later use. The rear bar is then secured to the frame with 4pcs removed screws and 4pcs nuts. As shown in the picture:



4. The installation is complete.



**Note:** Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.