

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

These *Side Mirrors* are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

Product picture



1. First distinguish the left and right sides of the rear view mirrors, and then find the right height on the original A-pillar, clamp the bracket of the mirror on the pillar, and push backwards with your palms at the same time, to make the claw be stuck more firmly on the pillar. As shown in the picture:







2. Use the matching iron bracket, hook one side on the pillar, and fix the other side on the mirror with screws, to make it hold the mirror better. (The other side of the side mirror can be installed in the same way as above). As shown in the picture:

Adjustable Side Mirrors for Polaris Ranger XP 1000



ZP-YJ-030505-026











Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.

3. Installation finished.