

# Front Corner Protectors Guards for Can-Am Commander



ZP-YJ-030606-012

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

The Front Corner Protectors Guards is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

## INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Assemble two parts 3 onto part 1 and part 2 using two M8 \* 45 hex screws and M8 jam nuts. As shown in picture:



2. Open the front cover of the hood, remove the four screws, and use four M6 \* 20 hex screws to install the iron bracket on the lower end of the front pillar. As shown in picture:



# Front Corner Protectors Guards for Can-Am Commander



ZP-YJ-030606-012



3. Assemble the lower end of the side bumper with the front bumper using two M8 \* 45 hex screws and two M8 jam nuts. As shown in picture:



4. Fix the upper end of the front bumper to the iron bracket using four M6 \* 20 hex socket screws and four M6 jam nuts. Tighten all bolts and complete the installation. As shown in picture:



**Note:** Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.