

Front Full Windshield for Can-Am Maverick R

ZP-YJ-030611-016

SAUTV5

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This FRONT FULL WINDSHIELD KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product image.



3. Assemble the windshield with 10 M6*20 screws, 10 M6 lock nuts and 10 M6 spacers.



4. Position the front windshield along the front of the frame.



5. Open the plastic panels on the left and right sides and secure the lower end of the windshield to the front post with two small straps.



Front Full Windshield for Can-Am Maverick R

ZP-YJ-030611-016

SAUTVS®



6. Secure the middle position of the windshield to the front post with two large straps.



7. Fix the top of the front windshield on the frame with two small straps and complete the installation.

