

Rear Full Windshield for Can-Am Maverick R

ZP-YJ-030611-017

SAUTV5

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This REAR FULL WINDSHIELD KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product image.



3. Remove the two screws in the rear window position as shown in the picture and install the two iron brackets.



4. Secure the rear window to the rear post first with two straps.



Rear Full Windshield for Can-Am Maverick R

ZP-YJ-030611-017

SAUTVS®

5. Fix the rear windscreen to the iron bracket with 2 x M6*20 socket head cap screws, 2 x M6 anti-loosening nuts.



6. Secure the top end of the rear windshield to the rear frame with two straps, installation complete.

