

# Bed Side Doors Kit For Can-Am Maverick R

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

## IMPORTANT

This BED SIDE DOORS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Secure the mounting bracket with 2 self-tapping screws as shown in the picture.



3. Snap the front end of the baffle into the two slots and tighten the back end with 2 quick release screws (Install the other side in the same way).



4. Installation completed.



**Note:** Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.