

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *Electronic Device Holder* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

PRODUCT AND ACCESSORIES



INSTALLATION INSTRUCTIONS

 Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
Place the device holder on the instrument. Drill holes on the instrument platform with a 3mm drill bit according to the fixing holes' position on the device holder, and then secure it using self-tapping screws. As the pictures show:





3. The installation is complete.





Electronic Device Holder For CFMOTO UFORCE 1000 ZP-YJ-031203-004





Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.