

Lower Protector Skid Plate for Can-Am Ryker

SAUTV5®

ZP-YJ-030603-178

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This LOWER PROTECTOR SKID PLATE KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Product image.



3. Remove the 4 self-tapping screws from the original vehicle's lower protector skid plate.

4. Secure the front guard under the frame with 4 self-tapping screws.



Lower Protector Skid Plate for Can-Am Ryker

SAUTV5®

ZP-YJ-030603-178



5. Fix the rear guard to the frame with 2 clamps, M6*20 screws and M6 nuts, and the center position is fixed with M10*30 self-tapping flange screws.



6. Installation completed.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.