

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This LED TAIL LIGHTS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

- 1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
- 2. Product image.



3. Remove the vehicle's original taillights and mounting brackets first (disconnect the taillights and reverse camera wiring harness plug-in in advance).

Note: If the vehicle is equipped with a rear bumper, you will need to remove it as well.









LED Tail Lights for Can-Am Maverick R

ZP-YJ-030601-008/ZP-YJ-030601-009



4. Install the new taillights onto the bracket and secure it with the vehicle's original screws.





5. Reinstall the taillight bracket back into the vehicle as disassembled and reconnect the taillight as well as the wiring harness plug-in for the reverse camera.







6. Installation completed.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.