

# Nerf Bars For CFMOTO ZForce 950

ZP-YJ-031206-001

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

This *Nerf Bars* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Assemble part 1 and part 2 through two bushing tubes (part 3) with four M8\*50 hexagon screws and four M8 anti-loose nuts but don't tighten the screws. The other side bar is assembled in the same way. As shown below:



3. Remove the cover plugs from the vehicle body.



4. Install the side bar to the two mounting holes with two M8\*20 flange outer hex screws and tighten the connection screws.



# Nerf Bars For CFMOTO ZForce 950

ZP-YJ-031206-001

---

5. Tighten all screws. Push all plugs cover. The installation is complete. (The other side bar is installed in the same way.)



**Note:** Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.