

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted. Please retain these installation instructions for future reference.

IMPORTANT

This FRONT FASCIA GRILLE KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

- 1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
- 2. Product image.



3. Assemble the separate front fascia as a whole, using M5*16 screws with flat washers and nuts.





4. Open the original front hood decorative plate, then unscrew the fixing screws under the original front fascia and disassemble the original front fascia, then install the new front fascia, use M6*16 screws to fix it, and finally install the hood decorative plate back.



Front Fascia Grille Kit for Can-Am Ryker

ZP-YJ-030603-185







5. Installation completed.



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.