

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

The A-arm Guards are exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product and accessories picture:



1. Secure the A-arm guards to the bottom of the front frame using 6 M6*20 hex screws, 6 M6 flat washers, and 6 clamps. As shown in picture:





2. Tighten 6 screws and complete installation. As shown in picture:





Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.