

Front Upper Storage Cargo Bin for Sea-Doo Spark

ZP-YJ-030608-008



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

The Storage Cargo Bin is exclusively designed for your boat. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTRUCTIONS

1.Products and accessories:




2.Plug the pointed rubber stopper on the lower frame of the storage box, as shown in the picture



3.Then fix the the lower frame on the front cover device of motorboat, hold it by hand,follow the screw hole positions on the frame, drill holes by 4.5mm drill bit, and then fix with screws. As shown in picture:

Front Upper Storage Cargo Bin for Sea-Doo Spark

ZP-YJ-030608-008



4. Find the limit blocks (left and right) of rubber handle and 2 screws, installed on the limit openings of both sides of the front storage box, (there is a square hole at the limit opening, there is also a square bump on the reverse side of the limit block of rubber handle, need to stick into the corresponding square hole when installation), follow the screw hole position on the limit block of handle, drill a screw hole with a pistol drill (4.5mm drill bit), and then fix it with screws, as shown in the picture.

5. Adjust the front and rear orientations of the storage box, and then put it into the motorboat, there are screw fixed points on both sides of the storage box. According to the position of the fixed points, drill holes with a pistol drill (4.5mm drill bit), and then fix it with screws (a flat washer needs to be threaded through the screw), as shown in the picture:

Front Upper Storage Cargo Bin for Sea-Doo Spark

ZP-YJ-030608-008



the lid can be installed, as shown in the picture:



6. There are two bayonets in the middle of the lower frame of the storage box. Press the top of the storage box lid against the bayonet, then

Front Upper Storage Cargo Bin for Sea-Doo Spark

ZP-YJ-030608-008



7. Installation finished.

